



Ditec DAB105

Swing doors

(translation of the original instructions)

IP2159EN • 2018-09-26

Technical Manual

Contents

	Subject	Page
1.	General safety precautions	3
2.	General safety precautions for the user	4
	Declaration of incorporation of partly completed machinery	5
	Revisions	6
3.	Technical specifications	7
4.	Standard installation	8
5.	Dimensions	9
6.	Main components	10
7.	Installation	11
7.1	Preliminary checks	11
7.2	General information	11
7.3	Installation examples	12
7.4	Removing the cover	12
8.	Automation with articulated arm DAB805PSA	13
8.1	Automation preparation and fastening	13
8.2	Fixing the arm	16
8.3	Assembling the left-hand articulated arm	16
9.	Automation with articulated arm DAB805PSAF	17
9.1	Automation preparation and fastening	17
9.2	Fixing the arm	20
10.	Automation with sliding arm DAB805PLA	21
10.1	Automation preparation and fastening	21
10.2	Fixing the sliding arm	25
10.3	Fixing the door stop	26
11.	Connecting to the electricity supply	27
12.	Starting up the door	28
13.	DAB105CU Electrical connections	29
13.1	Commands	29
13.2	Outputs and accessories	30
13.3	Adjustments	31
14.	Pre-configured parameters	33
15.	Door requisites for Low Energy use	34
16.	Example of an application with a standard automation	35
17.	ESE extension unit DAB905ESE (optional)	36
17.1	Commands	36
17.2	Outputs and accessories	38
17.3	Adjustments	38
17.4	Advanced settings available on the control panel version indicated, or subsequent versions	39
18.	DAB905ESA extension unit	40
18.1	Commands	40
18.2	Outputs and accessories	41
18.3	Adjustments	42
19.	Example of an application with optional extension units	43
20.	Parallel and interlocked automations	43
21.	Electrical start-up	47
22.	Routine maintenance plan	47
23.	Troubleshooting	48
24.	Signs	49

Key



This symbol indicates instructions or notes regarding safety, to which special attention must be paid.



This symbol indicates useful information for the correct functioning of the product.



This symbol advises you to contact the Technical Service.

1. General safety precautions



This installation manual is intended for qualified personnel only.

Installation, electrical connections and adjustments must be performed in accordance with Good Working Methods and in compliance with the present standards. Read the instructions carefully before installing the product.

Incorrect installation could be dangerous.



The packaging materials (plastic, polystyrene, etc.) should not be discarded in the environment or left within reach of children, as they are a potential source of danger. Before installing the product, make sure it is in perfect condition.

Do not install the product in explosive areas and atmospheres: the presence of inflammable gas or fumes represents a serious safety hazard.

Before installing the motorisation device, make all the necessary structural modifications to create safety clearance and to guard or isolate all the crushing, shearing, trapping and general hazardous areas.

Make sure the existing structure is up to standard in terms of strength and stability. The motorisation device manufacturer is not responsible for failure to observe Good Working Methods when building the frames to be motorised, or for any deformations during use.

The safety devices (photocells, safety edges, emergency stops, etc.) must be installed taking into account the applicable laws and directives, Good Working Methods, installation premises, system operating logic and the forces developed by the motorised door.

The safety devices must protect the crushing, shearing, trapping and general hazardous areas of the motorised door. Display the signs required by law to identify hazardous areas.

Each installation must bear a visible indication of the data identifying the motorised door.

When requested, connect the motorised door to an effective earthing system that complies with current safety standards.



During installation, maintenance and repair operations, cut off the power supply before opening the cover to access the electrical parts.

The automation protection casing must be removed by qualified personnel only.



The electronic parts must be handled using earthed antistatic conductive arms. The manufacturer of the motorisation declines all responsibility if component parts not compatible with safe and correct operation are fitted.

Only use original spare parts when repairing or replacing products.

The installer must supply all information on the automatic, manual and emergency operation of the motorised door, and must provide the user with the operating instructions.

All the rights concerning this material are the exclusive property of Entrematic Group AB.

Although the contents of this publication have been drawn up with the greatest care, Entrematic Group AB cannot be held responsible in any way for any damage caused by mistakes or omissions in this publication. We reserve the right to make changes without prior notice. Copying, scanning or changing in any way is expressly forbidden unless authorised in writing by Entrematic Group AB.

2. General safety precautions for the user



These precautions are an integral and essential part of the product and must be supplied to the user.

Read them carefully since they contain important information on safe installation, use and maintenance.

These instructions must be kept and forwarded to all possible future users of the system.

This product must only be used for the specific purpose for which it was designed.

Any other use is to be considered improper and therefore dangerous. The manufacturer cannot be held responsible for any damage caused by improper, incorrect or unreasonable use.

Avoid operating in the proximity of the hinges or moving mechanical parts. Do not enter within the operating range of the motorised door or gate while it is moving.

Do not obstruct the motion of the motorised door or gate, as this may cause a dangerous situation.

The motorised door or gate may be used by children over the age of 8 and by people with reduced physical, sensorial or mental abilities, or lack of experience or knowledge, as long as they are properly supervised or have been instructed in the safe use of the device and the relative hazards. Children must be supervised to make sure they do not play with the device, nor play/remain in the sphere of action of the motorised door or gate.

Keep remote controls and/or any other command devices out of the reach of children, to avoid any accidental activation of the motorised door or gate.

In the event of a product fault or malfunction, turn off the power supply switch. Do not attempt to repair or intervene directly, and contact only qualified personnel.

Failure to comply with the above may cause a dangerous situation.

Any repairs or technical interventions must be carried out by qualified personnel.

Cleaning and maintenance work must not be carried out by children unless they are supervised.

To ensure that the system works efficiently and correctly, the manufacturer's indications must be complied with and only qualified personnel must perform routine maintenance on the motorised door or gate. In particular, regular checks are recommended in order to verify that the safety devices are operating correctly.

All installation, maintenance and repair work must be documented and made available to the user.

Only lock and release the door wings when the motor is switched off. Do not enter within the operating range of the wing.



The crossed-out wheeled bin symbol indicates that the product should be disposed of separately from household waste. The product should be handed in for recycling in accordance with local environmental regulations for waste disposal. By separating a marked item from household waste, you will help reduce the volume of waste sent to incinerators or landfill and minimize any potential negative impact on human health and the environment.

Declaration of incorporation of partly completed machinery

We:

Entrematic Group AB
Lodjursgatan 10
SE-261 44 Landskrona
Sweden

declare under our responsibility that the following types of equipment:

Ditec DAB105

comply with the following directives:

2014/30/EU Electromagnetic Compatibility Directive (EMCD)
2006/42/EC Machinery Directive (MD) for the following essential health and safety requirements: 1.1.2, 1.1.3, 1.2.1, 1.2.3, 1.2.4, 1.2.6, 1.3.2, 1.3.4, 1.5.1, 1.5.2, 1.5.3, 1.5.8, 1.5.9, 1.5.10, 1.5.11, 1.6.3, 1.7.3, 1.7.4

Technical documentation for safe integration supplied.

Harmonised European standards which have been applied:

EN 60335-1:2012+A11:2014	EN ISO 13849 -1:2015	EN 61000 -6-2:2005
EN 60335-2-103:2015	EN 16005:2012/AC:2015	EN 61000 -6-3:2007+A1:2011

Other standards or technical specifications, which have been applied:

BBR BVL IEC 60335-1: 2010 ed.5 IEC60335-2-103:2002 ed.1+2011 ed.2.1 EN1634-1:2008

CE type examination or certificate issued by a notified or competent body (for the full address, contact Entrematic Group AB) for the equipment:

SC0250-14

The production process aims to guarantee that the equipment complies with the technical documentation.
The production process is regularly assessed by an independent body.

The equipment must not be put into service until the final door system installed has been declared compliant with the Machinery Directive 2006/42/EC by the installer.

Person in charge of technical data sheet:

Matteo Fino E-mail: matteo.fino@entrematic.com

Entrematic Group AB
Lodjursgatan 10
SE-261 44 Landskrona
Sweden

Place
Landskrona

Date
2018-09-26

Signature
Matteo Fino


Position
Entrance Automation President

Revisions


The following pages have been revised:

Page	Revision 2018-09-26
4	WEEE regulation
5	Declaration of incorporation of partly completed machinery
7	Added DAB805PLAT
34	Door requisites for "Low Energy" use
36	GND - O/C description
37	GND - KILL description, "NURSE & BED" FUNCTION
38	1-2 description
39	Management of electric lock / electric strike power supply
40	Extension unit DAB905ESA
44	Parallel automations

3. Technical specifications




DAB105																						
Power	100-240V~ +10/-15% 50/60 Hz																					
Consumption	max. 75W																					
Power supply for accessories	24V = 400 mA max.																					
Power supply fuse F1-F2	2xT6.3A 250 V																					
Opening time	min. 3s / 0°-80° max. 6s / 0°-80°																					
Closing time	min. 3s / 90°-10° max. 6s / 90°-10°																					
Door wing opening angle	DAB805PSA / DAB805PSAF / DAB805PLA/ DAB808PLAT : 110°																					
Max. inertia (J / kg²) Inertia J = $\frac{\text{door weight} \times (\text{door width})^2}{3}$ DAB805PSA/PSAF: 45kg m ² DAB805PLA/PLAT: 33 kg m ²	<table border="1"> <caption>Door Weight vs Door Width</caption> <thead> <tr> <th>Door Width [m]</th> <th>DAB805PSA/PSAF [kg]</th> <th>DAB805PLA/PLAT [kg]</th> </tr> </thead> <tbody> <tr><td>0.7</td><td>200</td><td>150</td></tr> <tr><td>0.8</td><td>200</td><td>150</td></tr> <tr><td>0.9</td><td>170</td><td>120</td></tr> <tr><td>1.0</td><td>140</td><td>100</td></tr> <tr><td>1.1</td><td>115</td><td>85</td></tr> <tr><td>1.2</td><td>90</td><td>65</td></tr> </tbody> </table>	Door Width [m]	DAB805PSA/PSAF [kg]	DAB805PLA/PLAT [kg]	0.7	200	150	0.8	200	150	0.9	170	120	1.0	140	100	1.1	115	85	1.2	90	65
Door Width [m]	DAB805PSA/PSAF [kg]	DAB805PLA/PLAT [kg]																				
0.7	200	150																				
0.8	200	150																				
0.9	170	120																				
1.0	140	100																				
1.1	115	85																				
1.2	90	65																				
	<table border="1"> <caption>OPSP/CLSP TRIMMER POSITION vs Door Weight</caption> <thead> <tr> <th>Door Weight [kg]</th> <th>OPSP/CLSP TRIMMER POSITION</th> </tr> </thead> <tbody> <tr><td>0 - 150</td><td>1 - 7</td></tr> <tr><td>150 - 200</td><td>1</td></tr> </tbody> </table>	Door Weight [kg]	OPSP/CLSP TRIMMER POSITION	0 - 150	1 - 7	150 - 200	1															
Door Weight [kg]	OPSP/CLSP TRIMMER POSITION																					
0 - 150	1 - 7																					
150 - 200	1																					
Type of operation	Motor opening Spring-plus-motor closure																					
Fire barriers	Applied using the arm DAB805PSAF																					
Maximum wing weight (see inertia graph)	150 kg DAB805PLA/PLAT 200 kg DAB805PSA																					
Door wing width	700 ÷ 1200 mm (DAB805PLA); 550-1200 mm (DAB805PSA - DAB805PSAF)																					
Minimum number of manoeuvres in AVERAGE conditions of use	1,000,000 cycles																					
Temperature	min. -20°C max. +45°C																					
Degree of protection	IP20 (FOR INTERNAL USE ONLY)																					

4. Standard installation





Ref.	Code	Description
1	DAB105	Electro-mechanical actuator
2		Control panel
3	DAB805PSA-PSAF DAB805PLA DAB805PLAT DAB805PLAB	Articulated movement arm (DAB805PSAF for applications on fire barriers) Sliding movement arm Movement arm with three levers Sliding movement arm (break-out/anti-panic)
4		Opening sensor
5	COM400MHB COM400MKB	Function selector switch
6		Command button
A		Connect the power supply to a type-approved omnipolar switch, with a contact opening distance of at least 3 mm (not supplied). Connection to the mains must be via an independent channel, separate from the connections to the control and safety devices.

5. Dimensions



6. Main components



Ref.	Code	Description
1		Base plate
2		Gearmotor
3	DAB105CU	Control panel
4		Power
5		End stop
6		Upper head
7		Lower head
8		Casing
9	DAB905ESE DAB905ESA	Safety and pulse extension card (optional) Extension card for safety functions (optional)
10		Cable fastener
11		Cable transit slits
12	DAB905BAT	Battery kit
13		Encoder
14		ON/OFF/HOLD OPEN switch
15		Shaft extension kit
		20mm 50mm 70mm 50mm
	DAB805SE2 DAB805SE5 DAB805SE7	
	DAB805SE5F	
		DAB805SE2 DAB805SE5 DAB805SE7 DAB805SE5F

7. Installation

The given operating and performance features can only be guaranteed with the use of DITEC Entrematic accessories and safety devices. Unless otherwise specified, all measurements are expressed in mm.

7.1 Preliminary checks

Check the stability and weight of the door wing. Make sure it moves smoothly, without any friction (reinforce the frame if necessary). Any "door closers" must be removed or completely annulled.

- Once you have made the slits for the cables to pass through, check the edges and smooth them if they are sharp, as they could damage the cables.
- To improve the degree of safety and the protection against vandalism, install the automation access inside the building if possible.
- Make sure the ambient temperature falls within the parameters indicated in the "Technical specifications" paragraph.
- Before you begin the installation, make sure the mains power supply is not connected.
- Check that the door wings and wall are adequately reinforced in the fixing points.
- Unpack the automation and make sure both it and its components are in good condition.
- Check the door wings have been built with suitable materials, and that there are no sharp corners. Any protruding parts must not create potential hazards. Sharp glass edges must not come into contact with other glass parts. You are advised to use tempered or stratified glass.
- Make sure there is no risk of getting trapped between the moving parts and the adjacent fixed ones when the door is opening. The following distances are considered sufficiently safe to avoid trapping the body parts indicated:
 - for the fingers: more than 25mm or less than 8mm
 - for the head: more than 200mm
 - for the feet: more than 50mm
 - for the whole body: more than 500mm

Fixing requisites

Material	Minimum requisites for the wall profile
Steel	5mm (reinforce with threaded rivets if the thickness is less than this)
Aluminium	6mm (reinforce with threaded rivets if the thickness is less than this)
Reinforced concrete	min. 50mm from the lower side
Wood	50mm
Brick	Anchor plug min. M6X85 UPAT PSEA B10/25 - min. 50mm from the lower side

7.2 General information

The DAB105 automation for swing doors can use articulated or sliding arms to open the doors.

The door is closed by a spring system, combined with the force of the motor.


The spring is pre-tensioned at 210°.



Do not alter the pre-tensioning of the spring unless it is strictly necessary.

7.3 Installation examples


The DAB105 automation for swing doors can be installed on one swing door, on two swing doors, or on two swing doors with a double exit.



7.4 Removing the casing

Remove the casing [8] by loosening the screw [Z].



NB: the product label is in the position shown in the figure below.






8. Automation with articulated arm DAB805PSA

Use the articulated arm for doors that open outwards (as seen from the automation side).



Shaft extension	X
/	30
DAB805SE2	50
DAB805SE5	80
DAB805SE7	100




8.1 Automation preparation and fastening



- Prepare the set-up for fixing the automation to the wall, respecting the measurements shown in the figures above (with reference to the hinge axis).
- Drill a hole in the door wing, in line with the fixing for the articulated arm.
- If necessary, use the DAB805SE2/SE5/SE7 extensions to increase the X measurement between the automation and the arm fixing points.




- Fix the automation in place using the screws [A]; tighten them firmly and evenly.
- Move the gearmotor sideways by loosening the 4 screws [B], so the base plate can be fixed in place.
- Fix the base plate with the screws [A].




- Return the motor to its original position.
- Fix the motor by tightening the 4 screws [B] supplied, in the sequence shown in the figure.


i Respect the measurement between the hinge and the gearmotor shaft output [C], as shown in the figure.



- Prepare the set-up for fixing the automation to the wall, respecting the measurements shown in the figures above (with reference to the hinge axis).
- Drill a hole in the door wing, in line with the fixing for the articulated arm.
- If necessary, use the DAB805SE2/SE5/SE7 extensions to increase the X measurement between the automation and the arm fixing points.




- Fix the automation in place using the screws [A]; tighten them firmly and evenly.
- Move the gearmotor sideways by loosening the 4 screws [B], so the base plate can be fixed in place.
- Fix the base plate with the screws [A].




- Return the motor to its original position.
- Fix the motor by tightening the 4 screws [B] supplied, in the sequence shown in the figure.

i Respect the measurement between the hinge and the gearmotor shaft output [C], as shown in the figure.

8.2 Fixing the arm




NB: open the door slightly and tighten the screw of the arm support seat [A] at 16 Nm (as shown in the figure).
If a torque wrench is not available, use a hexagon wrench of the type shown in the figure, gripping it on the long side and tightening very firmly.



- Move the door manually to check it opens and closes correctly, without any friction.
- With the door closed, fix the arm to the arm support [A] on the automation.
- Fix the bracket [B] to the door wing, forming an angle of 90°. Lengthen or shorten the arm [C] if necessary.

8.3 Assembling the left-hand articulated arm.




- In the case of automations with left-hand opening, you must invert the assembly of the articulated arm as shown in the figure.




9. Automation with articulated arm DAB805PSAF (for applications on fire barriers)

Shaft extension	X
/	48
DAB805SE5F	98



Y	Arm expansion
0-100	/
100-215	DAB805TFL
215-305	DAB805TFS DAB805TKJ




9.1 Automation preparation and fastening



- Prepare the set-up for fixing the automation to the wall, respecting the measurements shown in the figures above (with reference to the hinge axis).
- Drill a hole in the door wing, in line with the fixing for the articulated arm.
- If necessary, use the DAB805SE5F extension to increase the X measurement between the automation and the arm fixing points.




- Fix the automation in place using the screws [A]; tighten them firmly and evenly.
- Move the gearmotor sideways by loosening the 4 screws [B], so the base plate can be fixed in place.
- Fix the base plate with the screws [A].




- Return the motor to its original position.
- Fix the motor by tightening the 4 screws [B] supplied, in the sequence shown in the figure.


i Respect the measurement between the hinge and the gearmotor shaft output [C], as shown in the figure.



- Prepare the set-up for fixing the automation to the wall, respecting the measurements shown in the figures above (with reference to the hinge axis).
- Drill a hole in the door wing, in line with the fixing for the articulated arm.
- If necessary, use the DAB805SE5F extension to increase the X measurement between the automation and the arm fixing points.





- Fix the automation in place using the screws [A]; tighten them firmly and evenly.
- Move the gearmotor sideways by loosening the 4 screws [B], so the base plate can be fixed in place.
- Fix the base plate with the screws [A].




- Return the motor to its original position.
- Fix the motor by tightening the 4 screws [B] supplied, in the sequence shown in the figure.

i Respect the measurement between the hinge and the gearmotor shaft output [C], as shown in the figure.

9.2 Fixing the arm



- Move the door manually to check it opens and closes correctly, without any friction.
- With the door closed, fix the arm to the arm support [A] on the automation.
- Fix the bracket [B] to the door wing, forming an angle of 90°. If necessary, lengthen (using the arm lengthening kit) or shorten the arm [C].





NB: open the door slightly and tighten the screw of the arm support seat [A] at 25 Nm (as shown in the figure).
If a torque wrench is not available, use a hexagon wrench of the type shown in the figure, gripping it on the long side and tightening very firmly.




10. Automation with sliding arm DAB805PLA

Use the sliding arm for doors that open inwards (as seen from the automation side).




Shaft extension	X
/	50
DAB805SE2	70
DAB805SE5	100
DAB805SE7	120




10.1 Automation preparation and fastening



- Prepare the set-up for fixing the automation to the wall, respecting the measurements shown in the figures above (with reference to the hinge axis).
- Drill a hole in the door wing, in line with the fixing for the sliding arm.
- If necessary, use the DAB805SE2/SE5/SE7 extensions to increase the X measurement between the automation and the arm fixing points.






- Fix the automation using the screws [A], tightening them firmly.
- Loosen the screws [B] that hold the motor in place. Remove the motor. Fix the base plate with the 2 screws [A].
- Rotate the motor 180°, as shown in the figure.




- Fix the motor by tightening the screws [B] supplied, in the sequence shown in the figure.



i Respect the measurement between the hinge and the gearmotor shaft output [C], as shown in the figure.




- Prepare the set-up for fixing the automation to the wall, respecting the measurements shown in the figures above (with reference to the hinge axis).
- Drill a hole in the door wing, in line with the fixing for the sliding arm.
- If necessary, use the DAB805SE2/SE5/SE7 extensions to increase the X measurement between the automation and the arm fixing points.



- Fix the motor by tightening the screws [B] supplied, in the sequence shown in the figure.





- Loosen the screws [B] that hold the motor in place. Remove the motor. Fix the base plate with the 2 screws [A].
- Rotate the motor 180°, as shown in the figure.



- Fix the motor by tightening the screws [B] supplied, in the sequence shown in the figure.

i Respect the measurement between the hinge and the gearmotor shaft output [C], as shown in the figure.







10.2 Fixing the sliding arm



NB: open the door slightly and tighten the screw of the arm support seat [A] at 16 Nm (as shown in the figure).
If a torque wrench is not available, use a hexagon wrench of the type shown in the figure, gripping it on the long side and tightening very firmly.

- Move the door manually to check it opens and closes correctly, without any friction.
- With the door closed, fix the arm to the arm support [A] on the automation.
- Fix the guide [B] to the door wing, cutting off the excess part if necessary.

10.3 Fixing the door stop



The following operations must be carried out with the arm installed and the door closed.

In the case of installations with a sliding arm, proceed as follows:

- Remove the limit switches [B]. Loosen the door stop [A] and move it to the unknurled part of the drive arm.
- Rotate the limit switches by 180°. Reposition them on the gearmotor as shown in the figure.
- Reposition the door stop [A] as shown in the figure.




The door stop [A] must be fitted as close to the closure limit switch [B] as possible.

- Move the door manually to check it opens and closes correctly, without any friction.
- Adjust the internal open door stop [F], as indicated in paragraph 10.3.

11. Connecting to the electricity supply

Before connecting the power supply, make sure the plate data correspond to that of the mains power supply. An omnipolar disconnection switch with a contact opening distance of at least 3 mm must be fitted on the mains supply. Check there is an adequate residual current circuit breaker and overcurrent cut-out upstream of the electrical system. Use a H05RN-F 3G1,5 or H05RR-F 3G1,5 type electric cable. In the section outside the automation, the connection to the mains power supply must be via an independent channel separate from the connections to the control and safety devices. Make sure there are no sharp edges that may damage the power supply cable.




12. Starting up the door

Place the door in the closed position.




Rotate the SPTE trimmer on the control panel to 0° (if it is not already in this position).



Turn on the power supply.


Gradually rotating the SPTE trimmer clockwise, the door opens electrically. Slowly bring it to the required open position, plus about 15 mm.




Loosen the door stop [A]. Move it to the unknurled part of the arm.

Insert the door stop [A] in the groove, as close as possible to the opening limit switch [B].


If necessary, make a fine adjustment with the screw [C] on the opening limit switch.




Close the door by rotating the SPTE trimmer to 0°.



13. Electrical connections DAB105CU



Fix the label to the terminal board, taking care to apply it in the correct direction (see the figure above).




Optional extension units can be connected to the DAB105CU control panel: the DAB905ESE extension unit, or the DAB905ESA one, or both, depending on the required functions.

13.1 Commands

Contact	Function / Accessory	Description
1-2 GND-IIMP	NO OPENING - INNER SIDE	Contact closure activates the opening operation. The contact is always active if the ON-OFF-HOLD OPEN switch is present. The contact is controlled by the COM400MHB/MKB function selector switch (if present).
1-3 GND-XIMP	NO OPENING - OUTER SIDE, MANAGED BY THE ON-OFF-HOLD SWITCH	Contact closure activates the opening operation. The contact is only active if the ON-OFF-HOLD OPEN switch is present. DO NOT USE contact 1-3 or the ON-OFF-HOLD OPEN switch if the COM400MHB/MKB function selector switch is installed.
1-4 GND-OPD	NO Overhead presence detector (OPD), frame mounted	Overhead presence detector (OPD), frame mounted When an OPD sensor is mounted on the frame or operator cover just above the swing side of the door, it will—when activated—either keep the door open or closed. The sensor is not active during opening and closing. <ul style="list-style-type: none"> • a closed door will not open, if the OPD detects activity in the field. • an open door will not close, if the OPD detects activity in the field. • during opening, the door will continue to open, even if the OPD detects activity in the field. • during closing, the door will continue to close, even if the OPD detects activity in the field. • the OPD is not active in program mode OFF, manually opened door or during battery operation (Power Save Mode).
1-5 GND-LOUT	DO NOT USE	


Contact	Function / Accessory	Description
		<p>Automatic self-learning. When the door is started up, and on every spring tensioning variation, CLTQ trimmer variation, replacement of the extension units (DAB905ESE-DAB905ESA) or replacement of the electric lock / electric strike, it is necessary to perform an automatic self-learning operation.</p> <p> Make sure the door is fully closed. Move away from the door as soon as you have pressed the LRN button. The door has no safety settings during the automatic self-learning procedure. The door could suddenly slam shut.</p>
LRN		<p>By pressing the LRN button, the door launches an opening/closing operation for the automatic self-learning of the positions and of the opening/closing stops.</p> <p> DO NOT intervene during the self-learning procedure.</p> <p>During the closure phase, the spring pushes the door to acquire the door wing weight.</p> <p>By pressing the LRN button once, the door will open after 2 seconds. Press the LRN button twice to open the door immediately.</p> <p>In the case of double doors, the automatic self-learning operation must be carried out first on the MASTER door and then on the SLAVE door. The doors can be configured separately before connecting them with the synchronisation cable. In the case of door wing overlap and separate configurations, the MASTER door must be kept open until the SLAVE door has completed its own self-learning procedure.</p>

13.2 Outputs and accessories

Output	Description						
	<p>Output for the power supply to the accessories 24V = 400 mA max. NB: the maximum absorption of 400 mA corresponds to the sum of all the accessories installed.</p>						
<p>MOTOR</p> 	Motor connection						
<p>ENCODER</p> 	Encoder connection						
<p>ON/OFF</p> 	DO NOT USE						
<p>SYNC</p> 	<p>Connection for cable for synchronisation between two swing doors. For details about the operation, refer to the "SYNCHRONISED DOORS" chapter.</p>						
<p>ON/OFF/HOLD</p> 	<p>Connection of the ON/OFF/HOLD switch</p> <table border="1"> <tr> <td>ON</td> <td>The IIMP and XIMP opening contacts are enabled.</td> </tr> <tr> <td>OFF</td> <td>The XIMP opening contact is excluded.</td> </tr> <tr> <td>HOLD OPEN</td> <td>Door open.</td> </tr> </table>	ON	The IIMP and XIMP opening contacts are enabled.	OFF	The XIMP opening contact is excluded.	HOLD OPEN	Door open.
ON	The IIMP and XIMP opening contacts are enabled.						
OFF	The XIMP opening contact is excluded.						
HOLD OPEN	Door open.						

13.3. Adjustments

Trimmer

Trimmer	Description
SPT 	<p>Door start-up The SPT trimmer is used to make adjustments for the acquisition of the opening/closing stops when the door starts up.</p> <p>Spring tension adjustment The spring pre-tensioning is factory-set at 210°.</p> <p>i The maximum pre-tensioning of the spring is 210°. A greater tension could damage the spring or overheat the motor.</p> <p>To reduce/increase the pre-tensioning:</p> <ul style="list-style-type: none"> Loosen and remove the door stop (see chapter 10) Rotate the trimmer clockwise until the door opens at 45° Loose the fixing screw of the actuation arm Move the door towards the open position to reduce the spring tension Move the door towards the closed position to increase the spring tension (this operation is only possible if the spring has a pre-load less than the factory setting (210°) and no more than 210°). Tighten the fixing screw of the actuation arm Rotate the trimmer to minimum Open the door to the required open position plus about 15 mm, by rotating the trimmer clockwise Fix the door stop. For the fine adjustment, refer to chapter 10. Rotate the trimmer to minimum Press the LRN button to begin the door self-learning procedure
OPSP	<p>Adjustment of the opening speed time (from 3 to 6 s). Rotate the trimmer clockwise to increase the opening speed.</p> <p>ATTENTION. The opening and closing speeds are regulated according to the weight of the wing, as shown in the following diagram.</p>  
CLSP	<p>Adjustment of the closing speed time (from 3 to 6 s). Rotate the trimmer anticlockwise to reduce the closing speed.</p> <p>ATTENTION. The opening and closing speeds are regulated according to the weight of the wing, as shown in the following diagram.</p>  
POAS	<p>Adjustment of the servo-assisted movement during the manual opening of the door. With the trimmer at its minimum, the door is not servo-assisted. By rotating the trimmer clockwise, the motor increases the servo-assistance when the door is opened manually. The range of the POAS is depending on the spring pre-tension.</p>
CLTQ	<p>Closing force adjustment With the trimmer at its minimum, the door closes with the force of the spring. By rotating the trimmer clockwise, the motor increases the closing force. Increase the closing force on doors installed in environments with different pressure levels or subject to strong gusts of wind.</p>
HOT	<p>Adjustment of the automatic closing time (from 1.5 to 30 s) Adjust the time that passes between the end of the opening operation and the start of the closing operation. The count begins with the door fully open.</p>

Dip-switches

DIP	Description	OFF 	ON 
DIP1 - PAG	Push & Go The manual pushing of the door activates an automatic opening operation. When the door is closed, a closure thrust is maintained by the motor or the spring. Push and Go is not active in program selector setting DOOR CLOSED.	Disabled	Enabled
DIP2 - MAT	DO NOT USE		
DIP3 - SOS	Obstacle during opening	Stall If an obstacle is detected during the opening operation, the door continues to push and then closes after the time lapse set with the HOT trimmer.	Stop If an obstacle is detected during the opening operation, the door stops its movement and closes after 2 s.
DIP4 - ARM1 DIP5 - ARM2	Selection of the arm type. See the following table.		



The factory configuration is set for an articulated arm.
To alter DIP4 and DIP5, disconnect the mains power supply.
Select the arm type.
Restore the power supply.

Articulated arm DAB805PSA-PSAF (FACTORY SETTING)	DIP4 OFF 	DIP5 OFF 
Sliding arm DAB805PLA-PLAB 3-lever arm DAB805PLAT	DIP4 ON 	DIP5 OFF 

Signals

	ON 	OFF 	FLASHING 
LED	Normal operation	No mains power supply	Alarm (see the alarms table)

Alarms

 LED	CAUSE	SOLUTION
(1) 	External short circuit on 24V  Incorrect sensor detection	Check for short-circuiting or a damaged sensor
(2) 	Faulty battery	Replace the battery
(3) 	Faulty control panel	Replace the control panel
(4) 	Encoder error	Check the encoder cable. Manually open and close the door, then check the automatic function. If the problem persists, replace the control panel.
(5) 	Faulty blocking device	Check for short-circuiting in the blocking device Replace the blocking device
	Faulty DAB905ESE unit	Replace the DAB905ESE unit
(6) 	Synchronisation cable not connected, or faulty (parallel doors only)	Connect the cable
		Replace the cable
(7) 	SLAVE control panel faulty (parallel doors only)	Check the frequency of the flashes on the SLAVE LED, and adopt the necessary measures on the basis of this table
(8) 	Overheated motor	Wait for the motor to cool down
(9) 	Door blocked and repetitive command	Activate and deactivate the command

14. Pre-configured parameters

The DAB105 automation has 10 groups of pre-configured system-loaded parameters.

The group of parameters set in the factory corresponds to number 1.

To modify the group of parameters:

1. Disconnect the batteries (if installed).
2. Disconnect the mains power supply.
3. Press the LRN self-learning button, and keep it pressed.
4. Enable the power supply - the LED will light up  . Release the LRN self-learning button - the LED will switch off.
5. The LED flashes for a number of times corresponding to the number of the group of parameters (see the table).
6. Press the LRN button to pass to the next group of parameters after the set one. When you have reached the maximum limit of the parameters, you will restart from number 1.
7. Press the LRN button until you reach the required group of parameters.
8. Disconnect the mains power supply.
9. When the mains power supply is reconnected, the automation will use the new group of parameters.

Parameter group	1 (default)	2	3	4	5	6	7	8	9	10
Time of door open contact 3-5 ESE card (a)	15 min	endless	15 min	15 min	15 min	15 min	15 min	15 min	15 min	15 min
Battery use	Energy savings	Energy savings	Continuity	Energy savings	Energy savings	Energy savings	Energy savings	Energy savings	Energy savings	Continuity
Block mode with KILL command active	Blocked	Blocked	Blocked	Block managed by selector	Blocked	Blocked	Blocked	Blocked	Block managed by selector	Blocked
Obstacle during closure (b)	Closure	Closure	Closure	Closure	Reversal	Closure	Closure	Closure	Closure	Reversal
Motion sensor installed on synchronised doors. (c)	Separate detection	Separate detection	Separate detection	Separate detection	Separate detection	Common Limit	Separate detection	Separate detection	Separate detection	Separate detection
Block attempt on closure (d)	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Disabled	Enabled	Enabled	Enabled
O/C command opening/closing (e)	TWO-WAY mode	TWO-WAY mode	TWO-WAY mode	TWO-WAY mode	TWO-WAY mode	TWO-WAY mode	TWO-WAY mode	TWO-WAY / DOOR CLOSED / ONE-WAY mode	TWO-WAY mode	TWO-WAY mode
Configuration of emergency closure contact (KILL)	NO	NO	NO	NO	NO	NO	NO	NO	NC	NO

NOTES:

- (a) If the door stays open following an O/C open command, the control panel will launch a closure command after 15 minutes of inactivity.
- (b) If set in "CLOSURE" mode, the automation will stop if an obstacle is detected.
If set in "REVERSAL" mode, the automation will re-open. It continues to attempt the closure operation until the obstacle is removed.
With parameters set on 1 (factory setting), if there is a problem with block coupling during the closure phase, the door will attempt to enable the coupling twice in automatic mode, then once more in manual mode. This function can be disabled (see Parameter 7).
- (c) In the case of synchronised doors, the motion sensor can intervene independently on each door, or simultaneously.
- (d) If there is a problem with block coupling during the closure phase, the door will again close and attempt to enable the coupling.
- (e) With the ON/OFF/HOLD switch, the O/C command is always active except in the "HOLD - Door open" position.
With the program selector, the O/C command usually functions in TWO-WAY mode.
With Parameter 8 selected, the O/C command functions in TWO-WAY / ONE-WAY / DOOR CLOSED mode.

15. Door requisites for “Low Energy” use

The DAB105 automation is factory supplied with the setting “maximum performance”. For Low Energy use modify the classification as shown in the table

1. Disconnect the batteries (if installed).
2. Disconnect the mains power supply.
3. Press the LRN self-learning button, and keep it pressed. Enable the power supply.
4. The LED will light up   .
5. Release the LRN self-learning button - the LED will switch off.
6. The LED flashes as many times as the classification number (see table).
7. Press the LRN button to pass to the next classification number after the set one.
8. Press the LRN button until you reach the required classification.
9. Disconnect the mains power supply.
10. When the mains power supply is reconnected, the automation will use the new setting.

CLASSIFICATION	1 - Maximum performance (Default)	2 - Low energy
Standard	/	In accordance with DIN18650-2 (EN16005:2012)
Opening speed	3-6 s	Automatic limit 1,69J
Closing speed	3-6 s	Automatic limit 1,69J

The maximum setting for the opening speed and closing speed is automatically limited to the value indicated in the table; consequently, the speed may only be reduced.




Launch the automatic self-learning procedure (LRN button) after every parameter setting modification.

If necessary, adjust the OPSP and CLSP trimmers so that the opening and closing times are the same or longer than those indicated in the table in accordance with EN16005:2012 and ANSI 156.19 (the information in brackets refers to DIN 18650-2). The table shows the minimum opening times for opening of up to 80° and the minimum closing times for openings from 90° to 10°.



		Door wing weight [kg]				
		50	60	70	80	90
Door wing length [mm]	750	3,0 s (3,0 s)	3,0 s (3,2 s)	3,0 s (3,2 s)	3,0 s (3,3 s)	3,5 s (3,5 s)
	850	3,0 s (3,1 s)	3,0 s (3,1 s)	3,5 s (3,2 s)	3,5 s (3,4 s)	4,0 s (3,6 s)
	1000	3,5 s (3,2 s)	3,5 s (3,4 s)	4,0 s (3,7 s)	4,0 s (4,0 s)	4,5 s (4,2 s)
	1200	4,0 s (3,8 s)	4,5 s (4,2 s)	4,5 s (4,5 s)	5,0 s (4,8 s)	5,5 s (5,1 s)

16. Example of an application with a standard control panel




17. Extension unit DAB905ESE (optional)

There is a command extension card for managing the electric lock / electric strike, function selector, batteries, key selector switch and night-time closure.




i Fix the label to the terminal board, taking care to apply it in the correct direction (see the figure above).







17.1 Commands

Contact	Function - Accessory	Description
3 — 4 GND-OIMP	NO OUTER SIDE OPENING	Contact for connection of external detection radar. The closure of the contact activates an opening operation. NB: this command is only active with the COM400MKB-MHB function selector switch.
3 — 5 GND-O/C	NO OPEN/ CLOSE IMPULSE	The closure of the contact activates an opening operation. The door stays open until a new command is given. If the door does not receive any command, it closes automatically after 15 minutes of inactivity. Automatic closing cannot be adjusted using the HOT trimmer; it is factory-set. The automatic closing time can be modified from 15 min to endless (∞), setting the pre-configured parameter 2 as explained in chapter 14. With the ON/OFF/HOLD OPEN switch, the O/C command is always active except in the HOLD OPEN Position. With the program selector COM400MHB/MKB the O/C command usually functions in BI-DIRECTIONAL mode. If necessary, set the pre-configured parameter 8 as explained in chapter 14, the O/C command will function in BIDIRECTIONAL / MONO-DIRECTIONAL / DOOR CLOSE mode.
3 — 6 GND-KEY	NO KEY OPENING	The closure of the contact activates an opening operation. This command is always active, even when the COM400MHB/MKB function selector switch or ON-OFF-HOLD OPEN switch is installed. The automatic closure time is set to 5 s when the door is open regardless of HOT trimmer adjustment. Can be used for opening from night/CLOSED mode.

Contact	Function - Accessory	Description
3 — 7 GND-KILL	NO EMERGENCY CLOSURE (FIRE BARRIERS)	<p>The closure of the contact activates an emergency closure operation. This command is active in every situation, and has priority over every other command. When the contact has reopened (with JUMPER J=ON), the door resumes operating as set by the selector.</p> <p>! WARNING: if an EMERGENCY CLOSURE is activated, all the safety functions are ignored and the door closes. People or objects in the path of the door during the closing operation could suffer serious injury or damage. This function is generally used to cut off a specific area in the case of a fire. NB: this command can be combined with an emergency button. The output contact can be changed from NO to NC by altering the pre-configured parameters, as explained in chapter 13. The operation of the block during the emergency closure can be selected from the pre-set parameters explained in chapter 13. A panic bar can be installed in combination with a magnetic block on the fire barrier. In the event of a fire alarm or a power supply failure, the panic bar keeps the closed door blocked. In the case of escape routes, the panic bar can be manually released. Configure the relay contact of the DAB905ESA card, choosing parameter 11, 12 or 13 as explained in chapter 13.</p>
3 — 7 GND-KILL	NO "NURSE & BED" FUNCTION	<p>Available on the control panel version indicated, or subsequent versions. In installations with parallel doors, the "NURSE & BED" function can be enabled by connecting a switch to contacts 3-7 on the SLAVE door control panel.</p> <p>6DAB205CU 1801123456 11</p> <p>SOLUTION 1 Connect a bridge between 3 and 7 on the slave DAB905ESE. Use any impulse on master to open master door. Use O/C impulse on Slave to open both doors.</p>  <p>SOLUTION 2 Connect a bridge between 3 and 7 on the Slave DAB905ESE. Set dip switch PAG on Master board to ON. Use any impulse on master to open master door. Push slave door manually and it will open up automatically and stay open until master door is closing.</p> <p>SOLUTION 3 Connect a bridge between 3 and 7 on Slave DAB905ESE. Set dip switch PAG on Slave board to On. Any impulse on the master control unit: - Shorter than 2 s opens only master door. - Longer than 2 s opens both doors.</p> <p>Note: How to connect KILL input is determined by chosen parameter group at the slave, be sure that chosen group has KILL impulse configuration Normally Open. If KILL has to be Normally Closed, terminal 3 and 7 should be disconnected instead of connected.</p>

17.2 Outputs and accessories

Output	Description
	<p>Output for the power supply to the accessories 24V \approx 400 mA max. NB: the maximum absorption of 400 mA corresponds to the sum of all the accessories installed.</p>
	<p>Output for connecting an electric lock / electric strike. Select the type of power supply using the DIP1 and the type of electric lock / electric strike using the DIP2 With DIP2 in OFF (electric lock / electric strike Normal), and no COM400MHB/MKB function selector switch (or the latter in BIDIRECTIONAL mode), output 1-2 is permanently powered = door closed not locked. (referring status 1 chapter 17.4). If, on the other hand, you want to lock the door wing with the door closed, set the selector to BIDIRECTIONAL mode or make a jumper GND-EXIT (3-11). In this condition, output 1-2 is powered throughout the operation from opening until complete closure; for this reason, locks with mechanical reset cannot be used. With DIP2 in ON (electric lock / electric strike Anti-panic), the behaviour will be the same except for the fact that output 1-2 will always be unpowered in BIDIRECTIONAL mode and throughout the open/close operation in MONODIRECTIONAL mode". For different setting see Chapter 17.4 Management of electric lock / electric strike power supply.</p>
	<p>Output for connecting the function selector switch. If the function selector switch is on OFF, the Push and Go function is disabled. If a function selector switch is installed, disconnect the ON/OFF/HOLD switch (if present).</p>
<p>i For more information, refer to the COM400MKB-MHB selector manual.</p>	
<p>BATTERY</p> 	<p>BATTERY KIT If no mains power supply is available, the battery kit will guarantee operation in "energy-saving" mode. If no mains power supply is available, the door only operates with the key switch connected to 3 GND -6 KEY. In "energy-saving" mode, the door can remain stationary for up to a week while waiting for the KEY command. The following sensors are not active during "energy saving" operation: -OPD motion sensor -PIMP reversal safety contact -PDET opening safety device In this mode (on automations connected in parallel), connect the batteries only to the MASTER automation fitted with DAB905ESE. By changing the pre-configured parameter group, you can set the battery kit to CONTINUITY mode. If no mains power supply is available, the door operates normally until the batteries are fully discharged. In this mode, on automations connected in parallel, connect the batteries on both automations equipped with DAB905ESE. NB: for charging purposes, the battery kit must be connected to the control panel at all times. A new kit with fully-charged batteries can usually open and close a door consecutively in CONTINUITY mode. If you want to check the battery kit is working correctly, set DIP5=ON. In the event of a battery alarm, the DAB105CU control panel LED will flash twice.</p>
<p>i Monitoring of batteries must always be reset when batteries are replaced. To RESET press and hold the LRN button while battery mode is active (with mains power supply disconnected).</p>	
<p>An acoustic/light alarm signal can be connected to terminals 6-7-8 on the DAB905ESA card.</p>	

17.3. Adjustments

Trimmer

Trimmer	Description
	<p>Adjustment of the opening delay time, from 0 s to 3 s. With DIP3=ON, the door release is active throughout the opening delay.</p>

Dip-switches

DIP	Description	OFF 	ON 
DIP1	Power supply to the electric lock / electric strike.	12 V \approx max 500 mA	24 V \approx max 250 mA
DIP2	Type of electric lock / electric strike. DO NOT USE ELECTRIC LOCKS / ELECTRIC STRIKES WITH A RESET FEATURE.	Normal When it is powered, the door can be opened.	Anti-panic When it is unpowered, the door can be opened.
DIP3	Electric lock / Electric strike function	Disabled	Prior to the opening, a closure thrust is made simultaneously with the electric lock / electric strike activation impulse.
DIP4	Electric lock / electric strike coupling	Disabled	Enabled When it approaches the closing stop, the door increases its force/speed to ensure correct closure on the electric lock / electric strike.
DIP5	Battery test	Disabled	Enabled

Jumper


	Description	OFF 	ON 
	Emergency closure reset (FIRE BARRIERS ONLY)	Manual	Automatic

17.4 Advanced settings available on the control panel version indicated, or subsequent versions



Increased thrust force on closure when an electric lock is fitted


1. Disconnect batteries if any.
2. Disconnect the mains.
3. Press the LEARN BUTTON (LRN) and keep it depressed.
4. Connect the mains.
5. Watch the ERROR LED.



6. Release the LEARN BUTTON after 5 flashes (LED is out).
7. Identify the current lock kick status:
The ERROR LED flashes an amount of short flashes that correspond to the status number.
After a short pause the LED will repeat the status number and so on.
8. Changing the status:
If you push the LEARN BUTTON once, the status number will increase.
When you have reached the highest status number it will start at number one again.
 - Push the button until you get the requested lock kick status, 1=Basic (default), 2=Enhanced
 - Disconnect the mains
 Next time the mains is connected, the operator will use the new status setting.

Management of electric lock / electric strike power supply


1. Disconnect batteries if any.
2. Disconnect the mains.
3. Press the LEARN BUTTON (LRN) and keep it depressed.
4. Connect the mains.
5. Watch the ERROR LED.




6. Release the LEARN BUTTON after 6 flashes (LED is out).
7. Identify the current lock unlocked status:
The ERROR LED flashes an amount of short flashes that correspond to the status number.
After a short pause the LED will repeat the status number and so on.
8. Changing the status:
If you push the LEARN BUTTON once, the status number will increase.
When you have reached the highest status number it will start at number one again.
 - Push the button until you get the requested status.
 - 1= With DIP2 in OFF and no COM400 function selector switch (or the latter in two-way mode), output 1-2 is permanently powered (default) ; for this reason, locks with mechanical reset cannot be used.
 - 2= With DIP2 in OFF and no COM400 function selector switch (or the latter in two-way mode), when the operator received an open command, output 1-2 is powered through the first 10° of door opening and through the last 10° of closing; for this reason, locks with mechanical reset cannot be used. With the selector on BIDIRECTIONAL mode or with a jumper GND-EXIT (3-11), the output 1-2 is powered only through the first 10° of door opening; for this reason, locks with mechanical reset can be used.
 - Disconnect the mains.
 Next time the mains is connected, the operator will use the new status setting.

18. Extension unit DAB905ESA (optional)

There is a command extension card for managing motion sensors, alarm indications and door status.




i Fix the label to the terminal board, taking care to apply it in the correct direction (see the figure above).








i Remove the jumpers if a safety sensor is connected to terminals 1-2 and 1-3.

18.1 Commands

Contact	Function - Accessory	Description
 1 — 2 GND-PIMP	NC REVERSAL SAFETY CONTACT INTERNAL SENSOR	The opening of the contact during the closure manoeuvre causes the movement to invert (reopening). NB: the opening of the contact of the motion sensor installed on double doors causes both doors to re-open. The sensor is not active in DOOR CLOSED mode (set via the function selector switch), or when the door is opened manually due to a power failure or emergency closure (KILL).
 1 — 3 GND-PDET	NC OPENING SAFETY DEVICE EXTERNAL SENSOR	The opening of the contact causes the movement to stop during the opening phase. When the contact closes again, the automation resumes the interrupted opening operation. If the automation is closed, the opening of the contact prevents the opening operation. Adjust the safety exclusion trimmer so that the sensor does not detect the wall during the opening phase. During the opening phase, the safety sensor takes priority over the motion sensor. NB: the opening of the contact of the motion sensor installed on double doors causes both doors to stop, except in the case of double exit doors. Modify the operation of the double doors by changing the pre-configured parameters as explained in chapter 13. The sensor is not active in DOOR CLOSED mode (set via the function selector switch), or when the door is opened manually.
 5 — 4 24V-QTST	SAFETY TEST	Connect the QTST terminal of the control panel to the corresponding test terminal on the safety device. A test will be carried out on the safety device before every operation.

18.2 Outputs and accessories




Output	Description
	<p>Output for the power supply to the accessories 24V = 400 mA max.</p> <p>NB: the maximum absorption of 400 mA corresponds to the sum of all the accessories installed.</p>
<p>SAFETY SENSOR</p>	<p>Connect a self-checking safety sensor on the door wing. Connect the closing side sensor to terminals 1-2 (GND-PIMP). Connect the opening side sensor to terminals 1-3 (GND-PDET).</p>  <p>NB: in the event of a safety sensor fault during opening, the door closes and stays closed. It can only be opened manually. In the event of a safety sensor fault during closing, the door stays open. By switching the function selector switch to DOOR CLOSED, the door can operate in Low Energy mode. It can only be opened manually.</p> <p>i Remove jumpers 1-2 and 1-3.</p> <p>i For more information, refer to the REM sensor manual</p>
	<p>DO NOT USE</p>
	<p>Relay contact 24 V = 1A.</p> <p> The relay contact can be used as:</p> <ul style="list-style-type: none"> - an output for the parallel connection of the EMERGENCY CLOSURE command on several fire barriers; - an output for connecting a block with a power supply other than 12/24V DC; - an output for connecting an error warning device (light or acoustic). The COM-NO contact opens and the control panel detects an error (flashing LED on the DAB105CU control panel). If there is no alarm/error, the COM-NO contact is closed. In the event of an error, refer to the "Alarms" paragraph (24.1). <p> A device for indicating the open door can be connected. The open door position is adjusted by the opening safety exclusion trimmer. For a "door open" indication (from 45° to 90°), open the door with any opening command and adjust the trimmer until the LED on the DAB905ESA card lights up when the door is open (or is in the required opening position).</p>

18.3. Adjustments

Trimmer

Trimmer	Description
	Adjustment of the opening safety exclusion, from 45° to 90°. During the door opening phase, this excludes the functioning of the safety device installed on the door wing, so that the wall is not detected. When the safety device is excluded, the LED lights up.


Jumper

J1		Indication of external error / Output for parallel connection of Emergency Closure (KILL) / Block output
		Indication of door open
J2	OFF  ON 	Test on external sensor (GND-PDET)
	ON  OFF 	Test on internal sensor (GND-PIMP)
	ON  ON 	No test
	OFF  OFF 	Test on internal and external sensors (GND-PIMP / GND-PDET)


Signals

	ON 	OFF 
LED	Opening safety device disabled	Opening safety device enabled

19. Example of an application with optional extension units




20. Parallel automations (DAB905SYN)



Connect the two automations to the plug on the control panel, using the synchronisation cable (DAB905SYN). Depending on the type of installation, cut the jumpers on the MASTER or SLAVE cable, as shown in the table:

i The MASTER automation is the one that opens first.



Function		Door design				Cut the jumper with color	
Opening	Closing	Rebated	Jamming	No Jamming	Double egress	MASTER side	SLAVE side
Synchronous	Synchronous	/	/	YES	/	/	/
Synchronous	Asynchronous	YES	/	YES	/	BLACK	/
Asynchronous	Asynchronous	YES	YES	/	/	/	RED
Synchronous	Synchronous	/	/	/	YES*	BLACK	RED

(*) The operators works separately when received commands from installed safety sensors.


20.1 Settings

Operating mode	Settings	
	MASTER	SLAVE
Program selection	X	
Opening time	X	
Closure time	X	
Closure time adjustment	X	
Closure / Opening attempt when the door is obstructed	X	
Enable / Disable PAG	X	
Level of servo-assistance	X	X (*)
Closure force	X	X (*)
Pulse of motion sensor or mat	X	
Selection of operating mode during battery functioning	X	
Lock/release signal tension	X	X
Block powered / Unpowered	X	X
Enable / Disable block release	X	X
Open door delay	X	X
Enable / Disable snap block	X	X


(*) In double exit doors, these functions have to be set separately on the MASTER and SLAVE doors because the arm system and air pressure may differ.

- i**
- The electric locks / electric strikes must be connected to the MASTER and SLAVE control panels.
 - The opening devices must be connected to either the MASTER or SLAVE control panel, or to both.
 - The OPD motion sensor must be connected to the MASTER control panel except for double exit doors where each OPD motion sensor must be connected to the corresponding control panel
 - The sensors fitted on the wing must always be connected to the corresponding control panel.

20.2 Example of installation of parallel doors (DAB905SYN)



20.3 Interlocked automations



In applications for interlocked doors, a micro switch must be installed on the MASTER A automation in order to disable opening of the MASTER B automation and vice versa.

When both doors are closed, the 3-GND 7-KILL contact is open. The first automation that opens closes the contact and prevents the other automation from moving.

When the first automation has closed, the second automation can open by way of a second opening command.

NB: If a KILL command is given to the SLAVE automation, only the SLAVE door will stop.

NB: If single interlocked doors are installed, the same connections indicated above are used.

21. Electrical start-up



Before performing any type of operation, make sure that the automation is turned off and the batteries are disconnected.

The trimmers can only be adjusted with the automation idle.

1. Connect the motor and encoder cables to the DAB105CU control panel.
2. Turn on the power supply.
3. Press the LRN button for automatic self-learning.
4. In the case of parallel installations, the self-learning procedure must be carried out on the MASTER door first, then the SLAVE door. The self-learning procedures on the two doors can be carried out separately, before connecting the synchronisation cable. In the case of parallel doors with overlap, the MASTER door must stay open until the SLAVE door has completed its self-learning procedure.
5. Set the automatic closing time by means of the HOT trimmer.
6. Adjust the opening speed with the OPSP trimmer.
7. Adjust the closing speed with the CLSP trimmer.
8. Connect the accessories and check they are functioning.

22. Routine maintenance plan

Perform the following operations and checks every 6 months, according to the intensity of use of the automation.

Disconnect the 230V~ power supply and batteries (if present), and position the ON-OFF switch on OFF:

- Clean and lubricate the moving parts.
- Check the securing screws are firmly in place.
- Check all the electrical connections.
- Make sure the batteries are in good working order.

Restore the 230V~ power supply and batteries (if present), and position the ON-OFF switch on ON:

- Check the stability of the door, and make sure it moves smoothly.
- Check the condition of the pivots or hinges.
- Make sure all the command and safety devices are working properly.



NB: for spare parts, see the spares price list.




Only use original spare parts when repairing or replacing products.


The installer must supply all information concerning the automatic, manual and emergency operation of the motorised door or gate, and must provide the user with the operating instructions.

The installer must prepare and keep a maintenance record showing all the routine and extraordinary maintenance work carried out.

23. Troubleshooting

Problem	Possible cause	Solution / Explanation
The door does not open		
a) The motor does not start	The function selector is set on OFF	Change the function selector setting
	There is no mains power supply	Check the mains power supply
	The command unit does not work	Check the connections of the command accessories
	The motion sensor has been activated	Remove any objects from the detection area
	Emergency closure activated	Deactivate the emergency closure
	SPTe trimmer not set to 0°	Rotate the SPTe trimmer to 0°
b) The motor starts	Mechanical lock blocked	Release the lock
	Obstacle	Remove any obstacles
	Door stop jammed	Select block release
	The arm system is coming loose	Rotate the SPTe trimmer until the door stop is on the limit switch. Bring the door to its open position. Tighten the arm system. Rotate the SPTe trimmer to 0°
The door does not close	The selector is set on DOOR OPEN	Change the function selector setting
	The motion sensor contact has been activated	Remove any objects from the detection area
	Obstacle	Remove any obstacles
The spring pre-tensioning on the automatic system is unrecognised	Too many adjustments have been made	<ol style="list-style-type: none"> 1. Rotate the SPTe trimmer until the end stop can be loosened. 2. Remove the end stop and the arm system. 3. Disconnect the mains power supply. 4. Disconnect the motor cable 5. Replace the arm system and locate the non-pretensioning point by moving the door wing backwards and forwards. 6. Loosen the arm. 7. Reconnect the motor cable. 8. Reconnect the mains power supply. 9. Adjust the SPTe trimmer at 210° and wait for the shaft to stop rotating.  <ol style="list-style-type: none"> 10. Fix the end stop on the closure limit switch. 11. Set the SPTe trimmer to 0°. THE AUTOMATIC SYSTEM HAS RETURNED TO THE FACTORY SETTINGS. 12. Repeat the door start-up operations explained in chapter 12

24. Signs



Make sure the signs are in good condition, and attach them.

Obligatory indicates that this sign is required by the European directives and equivalent national legislation outside the EEC.

Ref.		Description
A		Product label. Obligatory.
B		Supervision of children. Obligatory, if applicable. Attach to both sides of the door. Attach to doors used by children, the elderly and disabled (as shown by a risk analysis).
C		Automation suitable for the transit of disabled people. Recommended, if applicable. Attach to both sides of the door.
D		Automatic door. Obligatory in the UK only.
E		Do not block the passageway. Obligatory in the UK only.
F		No access. Indicates one-way transit. Obligatory in the UK and USA only, if applicable.
G		Emergency break-out. Obligatory if approved for escape routes.
H		Door label. Obligatory, if applicable. Warns of the presence of glass door wings. Attach to all mobile glass door wings.
J		The automation can be activated by disabled people. Recommended, if applicable.

ENTRE//MATIC



Entrematic Group AB
Lodjursgatan 10
SE-261 44, Landskrona
Sweden
www.entrematic.com

